

SafeGuard School Bus Seat Cleaning Instructions

IMMI SafeGuard, as a manufacturer of school bus seats with seat belt systems, has closely followed these industry recommendations. These seat belt systems are personal protective safety devices regulated by Federal Motor Vehicle Safety Standards to achieve specific performance standards. We want to remind you of the cleaning procedures defined in our user manuals. Lack of adherence to these procedures may result in a degradation of product performance due to reactions of the restraint system components with cleaning chemicals. This potential degradation of performance may result in the system being unable to meet performance standards and may result in injury or fatality in the event of a crash.



*Approved mild soaps for solution with warm water are Ivory, Dreft, Woolite, and Dawn dishwashing soaps.

Below is the only process approved by IMMI SafeGuard for the cleaning of our SafeGuard School Bus Products.

- Care and maintenance of SafeGuard School Bus seats is the responsibility of the owner of the school bus vehicle with these seats.
- **Vinyl covered seat cushion, back and base:**
Use a damp sponge, towel or cloth with mild soap* and lukewarm water. Gently scrub the vinyl material. Apply a separate wet towel to wipe off any soap* residue. Allow 10 minutes to air dry.
- **Seat Belt Webbing:**
Wipe with a damp sponge, towel or cloth using mild soap* solution and lukewarm water. Allow 15-20 minutes to air dry.
- **Buckle and buckle components:**
Wipe clean with a damp sponge, towel or cloth with lukewarm water only. Never use cleaning products on buckles or buckle components. These cleaning products can cause harm to the mechanisms.
- **Never use lubricating agents** to clean because they will compromise the integrity the seat belt buckle and webbing retractor.

* ***Approved mild soaps for solution with warm water are Ivory, Dreft, Woolite, and Dawn dishwashing soaps.***

Cleaning, care and maintenance protocols are the responsibility of the owner. To maintain the integrity of the products, these instructions of IMMI SafeGuard must be followed. The owner assumes all responsibility for damages if he/she deviates from these cleaning instructions.

Please communicate these instructions to those within your organization responsible for the communication of care and maintenance instructions to your customers.

August 19, 2020 | 7700P

18881 IMMI Way | Westfield, IN 46074 USA | 317.896.9531 | FAX 317.896.2142 | imminet.com

SafeGuard 

safeguardseat.com